TOWING YOUR VEHICLE

By lifting
(two wheels only on the ground)

It is preferable to lift the vehicle by the wheels.

Without lifting
(four wheels on the ground)

You must always use a tow bar.

> Never use the radiator crossmember.

Special features of the automatic gearbox

When towing with all four wheels on the ground, the following rules must be adhered to:

- gear lever in position **N**,
- tow the vehicle at a speed less than 30 mph (50 km/h) over a distance of not more than 30 miles (50 km),
- do not add oil to the gearbox.



Front towing eye



Rear towing eye

From the front or the rear

Attach the tow bar to the towing eye.