FILLING WITH FUEL



Low fuel level

When the minimum fuel level in the tank is reached, this warning light comes on on the instrument panel.

You can still drive approximately 30 miles (50 km).

The engine must be switched off when filling with fuel.

- Open the fuel filler flap.
- Insert the key then turn it to the left.
- Remove the cap and hang it on the hook located on the inside of the flap.

A label affixed to the inside of the fuel filler flap indicates which type of fuel to use.

When you fill your tank, do not continue after the third cut-off of the pump. This could cause your vehicle to malfunction.

The capacity of the tank is approximately 60 litres.

- After filling the tank, lock the cap and close the fuel filler flap.

Operating fault

With the ignition on, if the fuel gauge needle remains in or returns to the rest position (below zero), this indicates a malfunction of the fuel gauge.

Contact a PEUGEOT dealer.

1.6 litre 16V BioFlex engine



Your BioFlex vehicle is an adaptable vehicle. It has been designed to run equally well on unleaded petrol (RON 95 or RON 98) or ethanol (in Europe, this is a mixture containing 85% ethanol and 15% unleaded petrol, referred to as E85).

So, irrespective of the quantity of fuel remaining in your tank and regardless of the type of fuel (unleaded petrol, E85 or a mixture of the two), you can fill your tank at any time with unleaded petrol (RON 95 or RON 98) or ethanol E85.

This vehicle will run on unleaded petrol only without experiencing any problems.

In wintry conditions, starting the engine from cold may sometimes prove difficult. During these very cold periods, it is advisable to favour unleaded petrol to guarantee optimum starting conditions.