EXTERIOR MIRRORS



Adjustment

☞ Move control **A** to the right or to the left to select the corresponding mirror.

☞ Direct control **B** in all four directions to adjust.

Folding back the mirrors electrically

- from inside:
  - ☞ With the ignition on, move the control **A** to the central position then pull it rearwards.
- from outside:
  - ☞ Lock the vehicle using the remote control* or the key.
  - ☞ This function can be deactivated. Consult a PEUGEOT dealer.

When the vehicle is parked, the exterior mirrors can be folded back manually.

Automatic tilting of the mirrors in reverse gear*

This function allows you to see the ground (kerb, wall...) when carrying out parking manoeuvres in reverse gear.

Initial setting of the function

Engage reverse gear then select and adjust the left mirror then the right mirror.

These settings will be stored when the vehicle is locked.

Each remote control stores a specific setting.

Tilting the mirror to the parking position

☞ engage reverse gear,

☞ move control **A** to the right or the left to select the corresponding mirror.

The exterior mirror corresponding to the side on which you are parking tilts downwards.

Intentional returning of the mirror to the driving position:

☞ change out of reverse gear or deselect the mirror.

The mirror returns to the driving position automatically if the vehicle speed exceeds 10 mph (15 km/h), if the engine is switched off or if reverse gear is engaged for more than 20 seconds.





Objects observed in the driver and passenger mirrors are, in reality, closer than they appear.

This must be taken into account in order to judge the distance of vehicles approaching from behind correctly.

* According to version.