FILLING WITH FUEL





The ignition must be switched off and the vehicle must be unlocked when filling with fuel.

- Open the fuel filler flap.
- Turn the cap to the left.
- Remove the cap and hang the end on the hook located on the inside of the flap.

A label affixed to the inside of the fuel filler flap indicates which type of fuel to use.

When you fill your tank, do not continue after the third cut-off of the pump. This could cause your vehicle to malfunction.

The capacity of the tank is approximately 67 litres.

- After filling the tank, screw on the cap and close the fuel filler flap.

Fuel warning

When this warning light comes on in certain driving conditions and depending on the engine, the distance which can be travelled with the fuel remaining may be less than 30 miles (50 kilometres).

Note: should you run out of fuel, you must add at least 6 litres.

Operating fault

A fuel gauge fault is indicated by the fuel level indicator needle returning to zero.

Consult a PEUGEOT dealer.

BioFlex engine



A Flex vehicle has been designed to run on unleaded petrol (RON 95 or RON 98) or ethanol (this is a mixture containing 85 % ethanol and 15 % unleaded petrol, called E85).
So, regardless of the quantity of fuel remaining in your tank and irrespective of its type (RON 95/RON 98, E85 or a mixture of the two), you can fill your tank at any time with unleaded petrol (RON 95 or RON 98) or ethanol (E85).
There is no problem driving on unleaded petrol only with this vehicle.

In winter conditions, starting the engine from cold may sometimes prove difficult. During these very cold periods you are advised to favour unleaded petrol to guarantee optimum starting conditions.